
Robotic Vision Project 2

Group 21

Karoline Amalie Halvorsen Anders Thallaug Fagerli Odin Aleksander Severinsen



Goal


Implement a 3D structure-based localization system and determine the exact position and orientation from a query photo

Background


Software:

- Python + OpenCV
- MATLAB
- COLMAP







Flowchart of Project




Core functionality - 2D - 3D inliner matches for a query image





Core functionality - localization of query image with the 3D model





How we calibrated Camera:

- OpenCV:
 - Cv2.findChessboardCorners
 - Cv2.calibrateCamera
- MATLAB
 - Camera Calibrator app

- COLMAP
 - fx: 4608, fy: 4608, cx: 1920, cy: 1080

3D Reconstruction

1. Python

SfM with OpenCV

2. COLMAP

3. MATLAB

SfM with Computer Vision Toolbox

1. Python


How did you acquire the 3D model and ensure its accuracy?

1. Python

SfM with OpenCV


- Camera intrinsic
- Descriptors- filter Lower
- Fundamental matrix with RANSAC

•



Keypoints + Descriptors

1. Python



Feature matching


• cv2.Flann.knnMatch


• K = 2

Ratio test: Lowe

900 features
0.8 threshold Lowe test
3 trees
Search param: 50

1. Python






Fundamental matrix

1. Python

- With LMEDS or RANSAC
- More robust than 8-point algorithm





Epipolar matching

1. Python










2. COLMAP

COLMAP


- Import descriptors from e.g
 OpenCV methods
 - Limited to 128 dimensional descriptor vector
- Feature matching by an exhaustive search
- 3D reconstruction by triangulation
- Pose estimation by bundle adjustment

















3. MATLAB

MATLAB


- 1. Build pose graph from consecutive frames, to scale
- Retrieves scale by bundle adjustment
- 3. Triangulates a dense point cloud from the refined poses
- 4. Gathers features from the point tracks identified by Matlab








2D - 3D matching






2D - 3D feature matching





Find Homography

Used method 0, that uses all the points. With Rancas to estimate



Pose estimation

1. Python

PnP with RANSAC

- Runs DLT inside a RANSAC loop to filter out outliers and compute P.
- Minimizes the reprojection error with Levenberg-Marquardt initialized with the DLT estimate

2. MATLAB

PnP with MSAC

- Uses MSAC for outlier removal in DLT
- Finds pose with P3P

Extra:

 solvePnP: Levenberg M: minimizing the reprojection error

Reference:

[1]: https://www.universeoptics.com/robotic-vision/

https://opencv.org/

https://colmap.github.io/

https://se.mathworks.com/help/vision/examples/structure-from-motion-from-multiple-views.html

https://piazza.com/class/k3o58n5yru0281